



**Model: 203 A2B2E2K2P3 R D**  
**P/N 124530000**

## FILTER

Combined filter with standard thread connector to **EN 148** for organic vapours having boiling point higher than 65°C, inorganic gases and vapours, Sulphur Dioxide (SO<sub>2</sub>), Ammonia (NH<sub>3</sub>) and its derivatives, dusts, fumes and mists.

The filter can be used with masks type **TR 82**, **TR 2002 CL2** and **TR 2002 CL3** or equivalent, provided that they are fitted with EN 148-1 connector



### TECHNICAL DATA

Inhalation resistance at 30 l/min: 1.8 mbar at 95 l/min: 6.6 mbar

#### Duration at gases

Filter type	Class	Testing Gas	Testing Concentration (PPM)	Testing Flow (l/min)	Testing HR (%)	Breakthrough concentration (PPM)	Duration Required (min)	Duration Tested (min)
A	2	C <sub>6</sub> H <sub>12</sub>	5000	30	70	10	35	48
B	2	Cl <sub>2</sub>	5000	30	70	0.5	20	32
		H <sub>2</sub> S	5000	30	70	10	40	46
		HCN	5000	30	70	10	25	>35
E	2	SO <sub>2</sub>	5000	30	70	5	20	28
K	2	NH <sub>3</sub>	5000	30	70	25	40	52

#### Performance particle filtration

Filter type	Penetration (l/min)	Testing Aerosol	Penetration Max Allowed (%)	Test 1 (%)	Test 2 (%)	Test 3 (%)
P R	95	NaCl	0.05	0.0019	0.0019	0.0008
		Paraffin oil	0.05	0.0007	0.0008	0.0009

Test Filter Type - Performance Particle Filtration to register:

Test 1: Penetration (media calculated 30 sec after the test beginning)

Test 2: Max Penetration till 120 mg aerosol exposition

Test 3: Penetration (media calculated 30 sec after the test beginning) after 120 mg aerosol exposition and 24h storage

Marking R means that the filter is reusable for more than one workshift.

« D » clogging test with Dolomite Dust.

Filter is submitted to an obstruction test with a concentration of Dolomite of 263 mg.h.m<sup>3</sup>. Inhalation resistance: a 95 l/min: 8.4 mbar (request < 10.5 bar)

<b>Filter type</b>	<b>Testing Flow</b>	<b>Testing Aerosol</b>	<b>Penetration Max Allowed (%)</b>	<b>Penetration Max Measured</b>
P R	95	NaCl	0.05	0.0008
		Paraffin oil	0.05	0.0008

Marking D means the filter passed the clogging test with Dolomite dust and it has high performance in dusty and sandy settings.